


FLYING LEADS/WIRES

Electrical connection option “R”



EXPLOSION-PROOF MODELS

Output	Red	Black	Green	White	Drain
mV (4-wire)	+V	Ground	+Signal	-Signal	Case
Voltage (3-wire)	+V	Ground	Case	Signal	N/A
4-20mA (2-wire)	+V	-V	Case	N/A	N/A

+V	Supply Voltage
-V	4-20mA Signal/Electrical Ground
Ground	Voltage Electrical Ground
Signal	Voltage Output Signal
Case	Case / Earth Ground
N/A	Not Applicable

WARNING!

Refer to the Explosion-Proof Operating Instructions prior to installation. Any mis-use or improper installation may impair the equipment’s intended use and/or protection ratings.



Thoroughly read and understand these wiring instructions prior to installation. **Please call Core Sensors at (862) 245-2673** if you are unsure about any of the instructions.

